

IL4442

## GLASS TABLE / FLOOR LAMP

These instructions are provided for your safety. Please read carefully before commencing work and retain for future reference.

## SAFETY INFORMATION

- \* The supply cable runs through the inside of the fitting. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- \* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- \* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- \* To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instructions before assembly.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Do not exceed wattage stated.
- \* When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of old bulbs carefully.

## **ASSEMBLY INSTRUCTIONS**

- 1. Unpack the table / floor lamp and remove all packaging. Be careful that you do not scratch surface of the stems whilst removing plastic wrapping.
- 2. Cover floor with a soft cloth to avoid damage to the flooring and surface of the product then lay this product out on the floor. Assembly should take place with the product lying flat.
- 3. Where required remove the plastic / cardboard cable protectors that are fitted at cable entry points inside stems and floor lamp base.
- 4. Firmly hold the lamp holder stem and then screw the middle stem into the upper section together, taking care to hold stems parallel to avoid cross threading.
- 5. Gently pull the excess cable out of lower stem until it meets assembled stems.
- 6. Hold assembled stems firmly and screw lower stem into the assembled stems. Make sure that the threads do not become crossed. If in doubt unscrew stem, then start again. **Take care not to over tighten**.
- 7. With the product laid on a covered surface attach the base onto assembled stems. Make sure that the threads do not become crossed. If in doubt unscrew base, then start again. **Take care not to over tighten**.
- 8. <u>TABLE & FLOOR:</u> Fit bulb, type and wattage as indicated on fitting. The wattage indicated must not be exceeded.
- 9. Carefully screw glass onto the lamp holder, **do not over tighten.**
- 10. Your floor lamp is now ready for use.

## **GENERAL INFORMATION**

This floor lamp is designed for internal use only. **Do not use polish or an abrasive cleaner - just a soft dry cloth.** 

To register your product for an extended five-year warranty, please complete the simple form at

www.darlighting.co.uk/warranty

You'll need to fill in the details of the product, the retailer you purchased it from, and also the installer and the installation. Please also upload a clear copy of the original purchase invoice or receipt to complete this registration.

UK: där Lighting Ltd, Wildmere Road, Banbury, Oxon, OX16 3JZ

Ireland & EU: Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18



IL4442

