


IL427

OUTDOOR WALL LIGHT



These instructions are provided for your safety.

Please read them carefully before commencing work and retain them for future reference.


SAFETY INFORMATION


- * If you are in any doubt consult a person competent to give advice on the installation of electrical equipment.
- * Before installation and servicing disconnect the electricity supply at the fuse board.
- * To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
- * This fitting should be fitted to a lighting supply protected by a 5 amp fuse or equivalent circuit breaker.
- * Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Dispose of old bulbs carefully.

INSTALLATION


Note: This fitting has a 3 year guarantee against corrosion. This fitting should only be installed in normal non aggressive atmospheric locations to prevent corrosion. Aggressive environments to be avoided include locations by the sea, polluted atmospheres or near heating flue outlets.

- 1. Ensure the house electricity supply is off at the fuse board.
- 2. If removing an existing fitting, first note down all wiring connections.
- 3. Unscrew nuts from front of backplate of wall bracket.
 - Remove mounting bracket from fitting and fix firmly to the wall. (Make sure that screws that go through fitting are level or fitting will not be straight when fixed to bracket.)
- 4. Unscrew four screws holding cover onto box.











- 7. Feed supply cable from house supply through hole in soft grommet which will form a seal around the cable
- 8. The weight of the fitting must be supported whilst you make the electrical connections.

Make all electrical connections through the connector block.

Ensure electrical connections are tight and no loose strands of wire are left out of the block.

Connect the live (brown) wire of the wall light to the supply live wire.

Connect the neutral (blue) wire of the wall light to the supply neutral wire.

- 9. Ensure electrical connections are tight and no loose strands of wire are left out of the connector block.
- 10. Replace cover on box.
- 11. Fix the fitting to the wall by threading the backplate onto the screws in the fixing bracket and holding in place with the nuts.
- 12. To fit bulb:

Remove glass by twisting glass anti-clockwise. Fit the bulb, type and wattage as indicated on the fitting. The wattage indicated must not be exceeded. Replacement of covers is a reversal of above instructions.

13. Switch on the electricity supply at the fuse board.



IL427

GENERAL INFORMATION

This fitting is designed for external use, it must be fitted to a DRY FINISH as any dampness in concrete, wood stain, paint and etc can damage finish. **Do not use polish or abrasive cleaner - just a soft slightly damp cloth.**

To register your product for an extended five-year warranty, please complete the simple form at

www.darlighting.co.uk/warranty

You'll need to fill in the details of the product, the retailer you purchased it from, and also the installer and the installation. Please also upload a clear copy of the original purchase invoice or receipt to complete this registration.

UK: där Lighting Ltd, Wildmere Road,Banbury, Oxon, OX16 3JZ **Ireland & EU**: Dar Lighting Ireland Limited, Suite 108, Q House, 76 Furze Road, Sandyford Industrial Estate, Dublin 18