

INSTALLATION MANUAL

38116P


ecolight




80
CRI



230V | SMD 2835 | 16W | IP44 | Aluminium + PC
Complete with 120mA driver.



one
LIGHT



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.