INSTALLATION MANUAL 62022AM




230V | SMD 2835 | 20W | IP20 | Sensor 30min timer |PC Complete with 450mA driver.












MICROWAVE MOTION SENSOR



By selecting the combination on the DIP switch, sensor data can be precisely set for each specific application.

	1	2	
ON	ON	ON	100%
1	ON	_	75%
	-	ON	50%
	_	_	25%

DETECTION SENSITIVITY

Detection area can be reduced by selecting the combination on the DIP switches to fit precisely each application.

	3	4	5	
ON 1	ON	ON	ON	5 S
	ON	ON	-	30 sec
	ON	-	ON	1 min
	ON	-	-	3 min
	-	ON	ON	5min
	-	ON	-	10 min
	-	-	ON	20 min
	-	-	-	30 min

ON TIMER

Refers to the time period the lamp remains at 100% illumination a er no motion detected.

		6	7	8	
ON	ON	ON	ON	2LUX	
	1	ON	ON	_	10LUX
		_	ON	-	25LUX
		ON	-	-	50LUX
		-	-	-	Disable

DAYLIGHT SENSOR

The sensor can be set to only allow the lamp to illuminate below a defined ambient brightness threshold. When set to disable mode, the daylight sensor will be unavailable and the light will not light up until motion was detected.

Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.