

INSTALLATION MANUAL

65018T


ecotrackspot



80 CRI



16W | SMD 2835 | 100-240V | 50/60Hz | IP20 | Aluminium + PC
Complete with 400mA driver.



one
LIGHT



<p>1</p> <p>To mount the track adaptor into the track system, first check that the selector knob is at position A. Move to position B to lock the adaptor.</p>	<p>2</p> <p>When installing the adaptor into the track, ensure that it is orientated correctly.</p>	<p>3</p> <p>Make sure that you also lock knob A for greater security.</p>
<p>4a</p> <p>Rotate selector knob A to the desired position circuit.</p>	<p>4b</p> <p>Circuit 1: To connect on circuit 1, from OFF position, rotate the knob A clockwise to position 1.</p>	<p>4c</p> <p>Circuit 2: To connect on circuit 2 rotate the knob A clockwise to position 2.</p>
<p>4d</p> <p>Circuit 3: To connect on circuit 3 rotate the knob A to position 3.</p>		

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.